



Deluxe Brush Display

70484

		Qty
21177	Deluxe Pan Brush	12 pcs.
21176	Deluxe Dish Brush	12 pcs.
21181	Deluxe Vegetable Brush	12 pcs.
21182	Deluxe Squeegee	12 pcs.
21175	Deluxe Utility Brush	12 pcs.
21180	Deluxe Toilet Brush	12 pcs.

Pieces 72



Shipping and Display included
Weight: 21 #

Chef Craft Corp.

PO Box 370
Pewaukee, WI 53072-0370
Phone: (800) 628-3794
Fax: (800) 416-7448
E-mail: orders@chefcraft.com
Web Site: www.chefcraft.com

70484
72 pieces
Deluxe Brush Display



Part #	Description	Qty,	UPC
21177	Deluxe Pan Brush	12 pcs.	 0 85455 21177 5
21176	Deluxe Dish Brush	12 pcs.	 0 85455 21176 8
21181	Deluxe Vegetable Brush	12 pcs.	 0 85455 21181 2
21182	Deluxe Squeegee	12 pcs.	 0 85455 21182 9
21175	Deluxe Utility Brush	12 pcs.	 0 85455 21175 1
21180	Deluxe Toilet Brush	12 pcs.	 0 85455 21180 5