



Scissors Display

70656

| | | |
|-------|--------------------|----|
| 20997 | Household Scissors | 36 |
| 21000 | Kitchen Shears | 36 |
| 21212 | Kitchen Scissors | 36 |

Pieces 108

Shipping and Base Included

Weight: 29#

Dimensions: 15in. X 13.25in. X 45in.

Cubes: 5.17 cu.ft.



Chef Craft Corp.

PO Box 370
Pewaukee, WI 53072-0370
Phone: (800) 628-3794
Fax: (800) 416-7448
E-mail: orders@chefcraft.com
Web Site: www.chefcraft.com

70656
108 pieces
Scissors Display



| Part # | Description | Qty. | UPC |
|--------|--------------------|------|-------------------------|
| 20997 | Household Scissors | 36 | 0 8 5 4 5 5 2 0 9 9 7 0 |
| 21000 | Kitchen Shears | 36 | 0 8 5 4 5 5 2 1 0 0 0 6 |
| 21212 | Kitchen Scissors | 36 | 0 8 5 4 5 5 2 1 2 1 2 3 |